

“ E-Z Hang” Trolley Hanger

- 1 Locate trolley hangers at each end of door to distribute load evenly.
(Minimum 3" from edge of door)

- 2 Drill 9/16" dia. holes in center of top rail of door.

- 3 Assemble as shown in illustration.

a. Position door height with adjustable nut.

b. Adjust laterally (in-out) by positioning door to desired operating clearance.
(Cam-bolt allows door to be positioned).

c. Lock in position with retainer clip and lock nut.

